

# Einstellungen

Bibliothek Wie

Scanning Offset Adjust

Enable Scanning Offset Adjustment

Speed	Line Shift	Initial Offs
50.0	0.400	0.000
100.0	0.750	0.000
150.0	1.080	0.000
200.0	1.450	0.000
250.0	1.725	0.000
300.0	2.050	0.000

Oversampling

Revision #1

Created 25 Juni 2024 11:18:39 by Andreas

Updated 25 Juni 2024 11:20:52 by Andreas